


# DMX-Relaisinterface 2

## DMX-Relaisinterface 2 SSR

User manual



**DMX** <sup>®</sup>  
**4**  
**ALL**

## Specification

The **DMX-Relaisinterface 2** is designed for switching tasks of several kinds.

Two potential free contacts with up to 8A switching power are available.

This relay interface is suitable for switching DC voltage or AC voltage.

A DMX FAIL function which can be activated optionally allows relays states unchanged at a loss of DMX signal.



The following operating modes are available:

- **Standard 2 channel Relaisinterface**  
2 autonomous switching outputs will be activated as soon as the DMX value reaches the range 128-255.
- **FogControl**  
2 switching outputs controlled by a DMX-channel. Thereby output 1 is for the heating element and output 2 for the pump control. An internal timer allows the automatic fog output.
- **Jalousie-Control**  
2 mutual locked switching outputs, controlled by 2 DMX-channels. Thereby is only one relay switched on, if the DMX value reaches the range 128-255.

## Technical data

Power supply:	12V DC / 250mA
DMX-channels:	1 or 2 channels, depending on operating mode
DMX-HOLD:	available
Operating modes:	Standard switching output Jalousie controlling FogControl
Output:	Standard Relais: 2 relay max. 8A / 250V~ SolidState-Relais: 2 break contact max. 2A /250V~
Board dimensions:	64,2mm x 82mm

## Connection



- = In the SolidState-Version not reserved

## LED-Display-Codes


The integrated DMX-LED is used as a multifunctional display. This LED lights non-stop in normal operation. If the LED does not light, there is no DMX512-input-signal.

Also the LED signalled the operation status. In this case the LED lights up in short pitches and then turns into off modus. The Number of flashing signals is equal to the Number of the error status.

Error Status	Error	Description
1	No DMX	There is no DMX-input signal
2	Address error	Check if a valid DMX- starting address is adjusted at the DIP-switch
3	DMX error	An invalid DMX input signal is established

## Addressing

The starting address is adjustable about the DIP-switch. Switch 1 has the valency  $2^0$  (=1), switch 2 the valency  $2^1$  (=2) and so on ... finally switch 9 has the valency  $2^8$  (=256). The sum of the switches which are moved to ON position, represents the starting address.



Address	Switch	Address	Switch
1		...	...
2		508	
3		509	
4		510	
5		511	

## DMX-HOLD function

The DMX-Relaisinterface 2 has a DMX-HOLD function that leave the state of the relais unchanged if the DMX signal fails.

If the DMX-HOLD function is not active so all relays are switched off during a failed DMX signal.

In a power failure the stored value is discarded!


DMX-HOLD is activated with switch 10:

- Switch 10 ON → DMX-HOLD activated
- Switch 10 OFF → DMX-HOLD not activated

## Selecting the operating mode

- **Standard**


Open all Jumper J1-J5 for this operating mode



DMX Channel	DMX Value	Function
1	0-127	Output 1 OFF
	128-255	Output 1 ON
2	0-127	Output 2 OFF
	128-255	Output 2 ON

- **FogControl**


Close only Jumper J1 for this operating mode



DMX Channel	DMX Value	Function
1	0-7	Device off
	8-20	Device on, no fog-emission
	21-40	Timer 10s on / 300s off *
	41-60	Timer 20s on / 350s off *
	61-80	Timer 30s on / 200s off *
	81-100	Timer 40s on / 150s off *
	101-120	Timer 50s on / 100s off *
	121-140	Timer 60s on / 75s off *
	141-160	Timer 70s on / 50s off *
	161-180	Timer 80s on / 40s off *
	181-200	Timer 90s on / 30s off *
	201-220	Timer 100s on / 20s off *
	221-240	Timer 110s on / 10s off *
141-255	Permanent fog-emission	

- **Jalousie-Control**

Close only Jumper J2 for this operating mode



DMX Channel	DMX Value	Function
1	0-127	Output 1 OFF
	128-255	Output 1 ON, if Output 2 OFF
2	0-127	Output 2 OFF
	128-255	Output 2 ON, if Output 1 OFF

## Equipment

### DIN-Rail housing 700



### Power Supply 12V / 20W



## CE-conformity



This assembly (board) is controlled by a microprocessor and uses high frequency (8MHz). To get the characteristics of the assembly in relation to the CE-conformity, an installation in a compact metal casing is necessary.

## Risk-Notes

You purchased a technical product. Conformance to the best available technology the following risks should not be excluded:

**Failure risk:** The device can drop out partially or completely at any time without warning. To reduce the probability of a failure a redundant system structure is necessary.

**Initiation risk:** For the installation of the board, the board must be connected and adjusted to foreign components according to the device paperwork. This work can only be done by qualified personnel, which read the full device paperwork and understand it.

**Operating risk:** The Change or the operation under special conditions of the installed systems/components could as well as hidden defects cause to breakdown within the running time.

**Misusage risk:** Any nonstandard use could cause incalculable risks and is not allowed.

**Warning:** It is not allowed to use the device in an operation, where the safety of persons depend on this device.



DMX4ALL GmbH  
Reiterweg 2A  
D-44869 Bochum  
Germany

© Copyright 2014 DMX4ALL GmbH

All rights reserved. No part of this manual may be reproduced in any form (photocopy, pressure, microfilm or in another procedure) without written permission or processed, multiplied or spread using electronic systems.

All information contained in this manual was arranged with the greatest care and after the best knowledge. Nevertheless, errors are to be excluded not completely. For this reason, I see myself compelled to point out that I can take over neither a warranty nor the legal responsibility or any adhesion for consequences, which decrease/go back to incorrect data. This document does not contain assured characteristics. The guidance and the characteristics can be changed at any time and without previous announcement.