Application Note

Setting the IP-address and Netmask with the IP-Configurator






Description

The **IP-Configurator** allows adjustment of the address and the netmask also if the PCs network setting is not within the IP-area of the DMX4ALL ArtNet Interface.

Configure the DMX4ALL ArtNet Interface

To adjust the network settings at first the DMX4ALL ArtNet Interface must be demand.

Therefore the software IP-configurator must be started. During the start the interface will be searched. If the search should be repeated please click *Find devices*.






For the reason that only the configuration occurs for the network settings ensure that only the interface to configure is within the network and is found!



Please click to the entry in the table and enter the IP and netmask.




Click **SET** to start the configuration.

Verify the confirmation request with *OK*.






The configuration will be carried out and afterwards the table entry will be updated.



Now the DMX4ALL ArtNet Interface is configured with the entered network settings. The further settings can be performed via the web browser.

For starting the web browser click to **Web config**.

The web browser opens and the configuration site loads:





Compatible devices

The software IP-Configurator is compatible with all DMX4ALL Interfaces.

Currently the following devices are compatible:

- ArtNet-DMX STAGE-PROFI 1.1
- ArtNet-DMX-Universe 4.1
- ArtNet-DMX-Universe DR 4.1
- ArtNet-LED-Dimmer 4
- ArtNet-LED-Dimmer 4R
- ArtNet-LED-Dimmer 6
- ArtNet-LED-Dimmer 6R
- ArtNet Multi PixxControl



The software IP-Configurator <u>doesn't</u> act together with the LAN-DMX STAGE-PROFI Interface !

► The network configuration is explained in the user manual.



DMX4ALL GmbH Reiterweg 2A D-44869 Bochum Germany